



BiOLUX
Restore Health Naturally

Actively kills
99.998%
coronavirus

Tested by
Nara Medical
University
in JAPAN



Just add WATER

No Harmful
By-products

Air & Surface
Sanitization

SPACE SANITIZER SYSTEM (SSS)

Bringing Nature's **MOST POWERFUL**
Sanitation Technology into Your Home



Kills **99.998%**
COVID-19 virus
& bacteria #2



Pure OZONE
& no harmful
by-products



Sanitize
up to 100m²



Decompose
harmful
formaldehyde



Deodorizes
unwanted
odours

Applications of Space Sanitizer System (SSS)

A tiny but mighty BiOLUX Space Sanitizer System (SSS)

Actively sanitize air and surface

It can be ideal companion for any environment



Living Room



Baby Room



Bedroom



Clinics/Hospitals



Nursery Centre/Schools



Office



Restaurant
/ Cafe



Fitness Centre
/ Studio



How Does Space Sanitizer System (SSS) Work?

OZONE flow through the air. Scatters to all corners of the room area



1. Pure OZONE (0.05 – 0.1 ppm)

Actively kills up to
99.998% coronavirus

2. Electrolysis Tank

Pure water passes through
OZONE Generator to produce OZONE

**Only Reverse Osmosis (RO) / Distilled water can be used*

3. Patented Electrolytic OZONE Generator (E.O.G.) Technology

Safe and no harmful by-product,
nitrogen oxides (NOx)

4. Humidifier Tank

Humidification function to reduce
the risk of droplet infection

**Only Filtered / Pure / Reverse Osmosis (RO) water
can be used*

5. PM2.5 HEPA Filter

It reduces contaminants
in air such as



Dust



Pet Dander



Hair



Smoke



Pollen

SPACE SANITIZER SYSTEM (SSS)

BiOLUX Space Sanitizer System (SSS) provides a **safe low-concentration OZONE** of **0.05 to 0.1 ppm**, which complies with the **OSHA occupational safety regulations** of the United States and can **help increase the environmental humidity to reduce the chance of droplet infection.**^{#1} This system is ideal for families with babies, toddlers and the elderly as well as those that enjoy frequent social gatherings.

PERFECT FOR:



Elderlies



People with asthma
& respiratory disease



Mothers
& babies



People
with pets



People with
allergies

FEATURES



Humidification
function



Natural
disinfectant

SPECIFICATIONS :

Model		EOS7190-R	
Mode		Comfort (Used when person(s) is present)	Boost (Used when no person(s) is present)
OZONE Concentration		0.05ppm*	0.1ppm**
Effective Coverage Space		Up to 100m ²	
Reservoir Capacity	Electrolysis Tank	0.2L (RO / Distilled Water)***	
	Humidifier Tank	1.2L (Filtered / Pure / RO Water)	
Humidification		100ml/hr (±15%)	
Power Supply		AC 100-240V, 50/60Hz, 32W	
Dimensions (WxDxH)		230 x 127 x 300 mm	
Weight (Net)		2.5kg	
Warranty		1-year warranty	

* Given values measured at 5cm from the fan outlet.

**Given values measured at 100cm from the fan outlet.

*** TDS < 1 ppm, Electrical Conductivity (EC) < 2µs/cm



Consumable Parts:

• OZONE generator (EOG)	About 6000 hours
• DI filter (DI)	1000 hours
• PM2.5 HEPA filter	1000 hours

*Under normal conditions, please replace the consumables according to the above suggestions to maintain product performance. Actual replacement time depends on actual usage.

#1 source: https://www.reuters.com/article/us-health-coronavirus-OZONE/japan-researchers-say-OZONE-effective-in-neutralising-coronavirus-idUSKBN25MOSO?feedType=mktg&feedName=healthNews&WT.mc_id=Partner-Google

#2 source: <https://pubmed.ncbi.nlm.nih.gov/29625986/>

SGS / Gmicro / NARAMed TESTED and Proven.

Product image is for reference only. All information in this brochure is subjected to change without prior notice. All logos and trademarks shown here are property of their representative owners. © 2021 Biolux Network (Asia) Sdn. Bhd. All Rights Reserved.